

## Installation instruction

The new TauRIS Terminal Software TS-UK 8.19 replaces the previous version of the Fancier software UK 8.18. All functions of the previous terminal software are also available within the new software version.

- Manual clock setting and manual clock control is no longer possible.
- On the Entry List and on the Clocking List, the setting time and the control time are extended by "Radio/Sat.sync."

The terminal software is loaded using the TauRIS Terminal Software Loader which you receive via download link. The TauRIS Terminal Software Loader is a PC software and is installed on the PC together with the TauRIS Terminal Software.

### Installation:

- 1) Click on the link you received by e-mail to download the "TauRIS Terminal Software TS UK 8.19".
- 2) Open the ZIP file.
- 3) Right-click on "setup.exe" and choose "Run as administrator".  
(The installation for the "TauRIS Terminal Software TS UK 8.19" starts).
- 4) Follow the instructions of the installation program.
- 5) When you see the "InstallShield Wizard Completed" screen with the message "The TauRIS Terminal Software has been successfully installed ...", click on <Finish> to complete the installation process. You will now see an icon on your desktop with the caption "TauRIS Terminal Software (TS UK 8.19)".
- 6) Double-click on the "TauRIS Terminal Software (TS UK 8.19)" icon to start the TauRIS Terminal Software Loader. You will see the main screen of the TauRIS Terminal Software Loader.

### Loading the software into the terminals:

- 7) Click on "Program" and "Set", select the COM-Port. Click on "save" to apply the settings.
- 8) Select the appropriate version (1 – 4 fanciers) in the menu bar <Terminal>.
- 9) Connect the terminal to the PC.
- 10) Press the button <6> and connect the terminal to the power supply.  
Keep button <6> pressed until the loading process starts!
- 11) After the terminal software was successfully loaded, the terminal beeps.
- 12) Load the fanciers loft stock into the terminal.

### System requirements:

For the installation of the TauRIS Terminal Software and the operation of the TauRIS Terminal Software Loader you need a PC (at least Pentium 4) with:

- A Windows operating system (Windows 7 or higher).
- A USB port for operating the terminal with a USB to serial converter to load data into the terminal or fetch it from the terminal.

### Hint:

The Club software CW 1.45-UK remains unchanged and is further on valid.

### Recommendation:

We recommend that you uninstall the TauRIS Terminal Software TS UK 8.18.