# Installation guide

**This guide is also valid for the TauRIS Club Software CW-INB 1.65, CW-INC 1.65, CW-INO 1.65.**

The TauRIS Club Software offers all functions to administrate clubs, fanciers, their pigeons, etc. except loading the TauRIS Terminal Software. For the Terminal Software an extra download link is available.

**Note:**
This version of the TauRIS Club Software installs in its own directory. Previous or older versions of the TauRIS Club Software remain unchanged.

**Installation:**

1) Right click on the “setup.exe” file and select “Run as Administrator". The installation program for the TauRIS Club Software now starts.
2) Follow the instructions of the installation program.
3) If the screen appears "InstallShield Wizard finished" with the hint "The TauRIS Club Software was successfully installed…" please click on <Finish> to finish the installation process. Now you can see an icon labeled "TauRIS Club 1.65" on the desktop.
4) Double click on the icon to start the TauRIS Club Software. You see the main screen of the TauRIS Club Software. For further guidance please read the manual enclosed.

**System requirements:**

For installation and operation of the TauRIS Club Software you need a PC (at least a Pentium 4) with:

- A Windows operating system (Windows 7 or higher).
- A serial interface (RS232, ComPort) or
- A USB interface. **Attention:** In this case you additionally need a USB to serial converter, to read data from the terminal or load data into the terminal.

We wish you successful racing season with
TauRIS – The Electronic Clocking System.